WOMEN'S HALF ELASTIC PANT SPECIFICATIONS			
SIZE	WAIST (+ OR - 1")	HIPS (+ OR - 1 1/2")	INSEAM
2	26	39	33 1/2 inches or shorter
4	27	40	33 1/2 inches or shorter
6	28	41	33 1/2 inches or shorter
8	29	42	33 1/2 inches or shorter
10	30	43	33 1/2 inches or shorter
12	31	44	33 1/2 inches or shorter
14	32	45	33 1/2 inches or shorter
16	33	47	33 1/2 inches or shorter
18	34	49	33 1/2 inches or shorter
20	35	50	33 1/2 inches or shorter
22	36	51	33 1/2 inches or shorter
24	37	53	33 1/2 inches or shorter

All measurements are in inches.

HOW TO MEASURE WAIST: Meausure just above hipbone at the natural waistline. Stand relaxed, not holding your stomach in, as this will result in an inaccurate measurement. INSEAM: Measure from base of crotch to top edge of shoe, standing upright. Try to wear the shoe that will be worn with the pants. HIPS: Measure around the fullest part of the buttocks.